SPECIAL WINTERIZATION INSTRUCTIONS FOR RV/MARINE INSTALLATIONS:

To winterize

your ARWXF129W washer,

- With washer-dryer power 1. OFF, pour 1/2 quart of RV-type antifreeze into washer drum; 2. Close door. Advance Cycle
- Selector to 'B':
- 3. Press ON/OFF button, then **WINTERIZE** press START. let the washerdryer run for 1 to 2 minutes;
 - 4. Press ON/OFF button to turn power OFF.
 - 5. Unplug washer-dryer from electrical outlet (or disconnect power);
 - 6. Turn water supply faucets OFF. Disconnect inlet hoses from faucets;
- END 7. Drain remaining water from the hoses. FINISHED.



www.splendide.com

To use your washer again,

- 1. Reconnect water inlet hoses to corresponding HOT/COLD faucets. Turn faucets ON. NOTE: Check water inlet hoses and pump periodically (see Users Guide);
- 2. Plug washer-dryer into appropriate electrical outlet (see Users Guide) - OR reconnect power supply;
- 3. With washer-dryer power OFF, pour 1/2 TBSP. of powder detergent (or liquid equiv.) into compartment '2' inside Dispenser Drawer;
- ERIZE 4. Advance Cycle Selector to position '4';
- WINT 5. Press ON/OFF button, then press START.
 - 6. Allow machine to run through the complete cycle to clean out any remaining antifreeze. FINISHED.

END

Optional Winterization

Instructions

If you're currently pumping antifreeze through your fresh water system, you can follow these steps to winterize your washer-dryer:

- 1. With machine power OFF, advance Cycle Selector to position '3';
- 2. Press ON/OFF button. set water temperature to WARM, then press START. Let machine fill until the drum turns (could take up to 1 to 2 minutes);
- 3. Press ON/OFF button to turn power OFF;
- 4. Advance Cycle Selector to 'B';
- 5. Press ON/OFF button, then press START.
- 7. After letting antifreeze drain completely from drum, press the **ON/OFF** button to turn power OFF. FINISHED.

IMPORTANT! DO NOT DISCARD! Keep this page with your owners manual for future reference

Ninterization Option

END