

RV 760/Camper 760 Owner's Manual



All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin[®] and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin.

BaseCamp[™], HomePort[™], MapSource[®], myGarmin[™], ecoRoute[™], myTrends[™], trafficTrends[™], nüMaps Guarantee[™], and nüMaps Lifetime[™] are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth[®] word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license. microSD[™] and the microSDHC logo are trademarks of SD-3C, LLC. Windows[®], Windows Vista[®], and Windows XP[®] are registered trademarks of Microsoft Corporation in the United States and other countries. Mac[®] is a trademark of Apple Inc. ACSI[™] is a trademark of Auto Camper Service International Holding B.V. HD Radio[™] and the HD logo are trademarks of iBiquity Digital Corporation. HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and foreign patents.

Table of Contents

Getting Started 1
Connecting the Device to Vehicle Power
Support and Updates 1
Setting Up Garmin Express
nüMaps Guarantee™1
Lifetime Subscriptions 1
Entering and Exiting Sleep Mode
Turning Off the Device
Resetting the Device
Acquiring GPS Signals
Entering an RV Profile
Activating an RV Profile
Adjusting the Screen Brightness
Adjusting the Volume
About Automatic Volume
Status Bar Icons
Viewing GPS Signal Status
Battery Information
Setting the Time 2
Using the On-Screen Buttons 2
Using the On-Screen Keyboard 2
Using a Backup Camera
Locations
Finding Locations
Finding a Location by Category 3
Finding a Location Using the Search Bar3
Changing the Search Area
Finding a Location by Browsing the Map 3
Finding an Address 3
Finding Recently Found Destinations 4
Finding Parking 4
Search Tools 4
Saving Locations
Saving a Location
Saving Your Current Location
Saving a Home Location
Editing a Saved Location 4
Assigning Categories to a Saved Location
Deleting a Saved Location
Setting a Simulated Location
Adding a Shortcut
Removing a Shortcut
Custom Points of Interest
Installing POI Loader
Using the POI Loader Help Files
Finding Custom POIs 5
Navigation5
Transportation Modes
Choosing a Transportation Mode
Starting a Route
Previewing Multiple Routes
Changing the Route Calculation Mode
Starting a Route to a Saved Location
Your Route on the Map
Using the Navigation Map
Adding a Point to a Route
Taking a Detour
Stopping the Route
Viewing Route Activity
Viewing a List of Turns
Viewing the Next Turn
Viewing Junctions
Warning Icons

Road Condition Warnings	
About Up Ahead	
Finding Upcoming Points of Interest	
Customizing the Up Ahead Categories	6
Trip Information	
Viewing Trip Data from the Map	. 6
Viewing the Trip Information Page	6
Viewing the Trip Log	
Resetting Trip Information	
Using Suggested Routes	
Viewing Current Location Information	7
Finding Nearby Services	
Getting Directions to Your Current Location	
Avoiding Road Features	
About Custom Avoidances	
Avoiding an Area	
Avoiding a Road	
Disabling a Custom Avoidance	
Deleting Custom Avoidances	
Customizing the Map	
Customizing the Map Tools	
Customizing the Map Layers	
Changing the Map Data Field	
Changing the Map Perspective	
Safety Cameras	8
Traffic	8
Receiving Traffic Data Using a Traffic Receiver	
Traffic Receiver	
Positioning the Traffic Receiver	
Viewing Upcoming Traffic	
Viewing Traffic on the Map	
Searching for Traffic Incidents	
Traffic on Your Route	
Taking an Alternate Route	
About Traffic Cameras	
Saving a Traffic Camera	
Viewing a Traffic Camera	
About Traffic Subscriptions	9
Subscription Activation	
Viewing Traffic Subscriptions	
Adding a Subscription	
trafficTrends™	
Disabling trafficTrends	
Enabling Traffic	9
Voice Command	9
Setting the Wakeup Phrase	
Activating Voice Command	
Voice Command Tips	
Starting a Route Using Voice Command	9
Muting Instructions	
Disabling Voice Command1	10
-	
Hands-Free Phone Calls1	
About Hands-Free Calling1	
Enabling Bluetooth Wireless Technology	
Pairing Your Phone 1	
Tips After Pairing the Devices 1	
Disconnecting Your Phone 1	
Deleting a Paired Phone 1	
Placing a Call 1	
Dialing a Number 1	
Calling a Contact in Your Phone Book 1	10
Calling a Location1	
Receiving a Call 1	10
Using the Call History 1	
Using In-Call Options 1	

Saving a Home Phone Number Calling Home	
Using the Apps	11
Using Help	
Searching Help Topics	
Smartphone Link	11
Downloading Smartphone Link	11
Connecting to Smartphone Link	
Sending a Location from Your Phone to Your Device	
Disabling Calls While Connected to Smartphone Link	
Garmin Live Services	
Subscribing to Garmin Live Services	
Finding Your Last Parking Spot	
About ecoRoute ecoRoute HD Accessory	
Setting Up the Vehicle	
Changing the Fuel Price	
Calibrating the Fuel Economy	
About ecoChallenge	
Viewing Fuel Economy Information	12
Mileage Reports	
Resetting ecoRoute Information	12
Viewing myGarmin Messages	
Viewing the Weather Forecast	
Viewing Weather Near a Different City	
Viewing the Weather Radar	
Viewing Weather Alerts	
Checking Road Conditions	
Planning a Trip Scheduling a Trip	
Navigating to a Saved Trip	
Editing a Saved Trip	
	13
Viewing Previous Routes and Destinations	
Viewing Previous Routes and Destinations Data Management	13
Viewing Previous Routes and Destinations Data Management File Types	13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards	13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card	13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer	13 13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer	13 13 13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable	13 13 13 13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device	 13 13 13 13 13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings	 13 13 13 13 13 13 13 13 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps	 13
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Enabling Maps	 13 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Editing an RV Profile Navigation Settings	13 13 13 13 13 13 13 13 13 13 14 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Enabling Maps	13 13 13 13 13 13 13 13 13 13 14 14 14
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Editing an RV Profile Navigation Settings Route Preferences. Display Settings Bluetooth Settings Disabling Bluetooth	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Editing an RV Profile Navigation Settings Route Preferences. Display Settings Bluetooth Settings Disabling Bluetooth Traffic Settings Units and Time Settings	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Editing an RV Profile Navigation Settings Route Preferences Display Settings Bluetooth Settings Disabling Bluetooth Traffic Settings Units and Time Settings Language and Keyboard Settings	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14
Viewing Previous Routes and Destinations Data Management File Types About Memory Cards Installing a Memory Card Connecting the Device to Your Computer Transferring Data From Your Computer Disconnecting the USB Cable Customizing the Device Map and Vehicle Settings Enabling Maps Editing an RV Profile Navigation Settings Route Preferences Display Settings Disabling Bluetooth Traffic Settings Units and Time Settings Language and Keyboard Settings Device and Privacy Settings	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 14
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 14 14 14 14 14 14
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 15
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 15 15
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 14 14 14 15 15 15
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 15 15 15 15
Viewing Previous Routes and Destinations	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 15 15 15 15 15
Viewing Previous Routes and Destinations Data Management	13 13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 15 15 15 15 15 15 15 15
Viewing Previous Routes and Destinations Data Management	13 13 13 13 13 13 13 13 13 14 14 14 14 14 14 14 15 15 15 15 15 15 15 15 15 15 15 15 15
Viewing Previous Routes and Destinations	$\begin{array}{c} \textbf{13} \\ \textbf{14} \\ \textbf{15} \end{array}$
Viewing Previous Routes and Destinations Data Management	$\begin{array}{c} \textbf{13} \\ \textbf{14} \\ \textbf{15} \\$

Removing the Device from the Mount Removing the Mount from the Suction Cup Removing the Suction Cup from the Windshield Purchasing Additional Maps Purchasing Accessories	. 15 . 15 . 15
Troubleshooting	.15
The suction cup will not stay on my windshield	
My device is not acquiring satellite signals	
The device does not charge in my vehicle	
My battery does not stay charged for very long	
The battery gauge does not seem accurate	
My device does not appear as a removable drive on my	
computer	16
My device does not appear as a portable device on my	. 10
computer	16
My device does not appear as either a portable device or a	. 10
	16
removable drive or volume on my computer	
My phone will not connect to the device	
Index	.17

Getting Started

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Connecting the Device to Vehicle Power

🛆 WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

Before you use your device on battery power, you should charge it.

1 Plug the vehicle power cable ① into the USB port on the mount.



2 Press the mount ② onto the suction cup ③ until it snaps into place.

The Garmin[®] logo on the mount should face right-side up.

- **3** Press the suction cup to the windshield, and flip the lever ④ back toward the windshield.
- **4** Fit the tab on the top of the mount into the slot on the back of the device.
- 5 Press the bottom of the mount into the device until it clicks.
- 6 Plug the other end of the vehicle power cable into a power outlet in your vehicle.

Support and Updates

Garmin Express provides easy access to these services for your device.

- Product registration
- · Software and map updates
- Product manuals
- · Vehicles, voices, and other extras

Setting Up Garmin Express

- 1 Plug the small end of the USB cable into the port on the device.
- 2 Plug the larger end of the USB cable into an available USB port on your computer.
- 3 Go to www.garmin.com/express.
- 4 Follow the on-screen instructions.

nüMaps Guarantee™

Your device may be eligible for a free map update within 90 days of first acquiring satellites while driving. Go to www.garmin.com/numaps for terms and conditions.

Lifetime Subscriptions

Some models include subscriptions to lifetime features. For more information, go to www.garmin.com/lmt.

LT: This model includes a lifetime traffic subscription and a traffic receiver.

- LM: This model includes a nüMaps Lifetime™ subscription, which provides quarterly map updates for the useful life of your device. For terms and conditions go to www.garmin.com/us/maps/numaps_lifetime.
- **LMT**: This model includes a nüMaps Lifetime subscription, lifetime traffic subscription, and a traffic receiver.
- **LMTHD or LMT-D**: This model includes a nüMaps Lifetime subscription, lifetime digital traffic subscription, and a digital traffic receiver.

Activating Lifetime Maps

- **1** Go to www.garmin.com/express.
- **2** Follow the on-screen instructions.
- **NOTE:** If you register the device, you can receive e-mail notifications when a map update is available.

Entering and Exiting Sleep Mode

You can use sleep mode to conserve battery power when your device is not in use. While in sleep mode, your device uses very little power and can wake instantly for use.

TIP: You can save power by putting the device in sleep mode while charging the battery.

Press the power key 1.



Turning Off the Device

- 1 Hold the power key until a prompt appears on the screen. The prompt appears after five seconds. If you release the power key before the prompt appears, the device enters sleep mode.
- 2 Select Off.

Resetting the Device

You can reset your device if it stops functioning. Hold the power key for 10 seconds.

Acquiring GPS Signals

To navigate with your device, you must acquire satellites. **...II** in the status bar indicates the satellite signal strength (see page 2). Acquiring satellites can take several minutes.

- 1 Turn on the device.
- 2 If necessary, go outdoors to an open area, away from tall buildings and trees.
- 3 If necessary, hold **III** to view detailed information about the satellite signals.

Entering an RV Profile

Entering your vehicle profile characteristics does not guarantee that your vehicle's characteristics will be accounted for in all route suggestions or that you will receive the warning icons in all cases. Limitations may exist in the map data such that your device cannot account for these restrictions or road conditions in all cases. Always defer to all posted road signs and road conditions when making driving decisions.

- 1 Select Settings > RV Profile.
- 2 Select RV.
- 3 Select ∔.
- **4** Follow the on-screen instructions.

Activating an RV Profile

Before you can activate a profile, you must add the profile (page 1).

The device calculates routes based on the width, length, height, weight, and other settings for the active profile.

- 1 Select Settings > RV Profile > RV.
- 2 Select the profile.
- 3 Select Select Profile.

Adjusting the Screen Brightness

- 1 Select Settings > Display > Brightness.
- 2 Use the slider bar to adjust the brightness.

Adjusting the Volume

- 1 Select Volume.
- **2** Select an option:
 - · Use the slider bar to adjust the volume.
 - Select 🖄 to mute the device.
 - Select **** for additional options.

About Automatic Volume

On devices with hands-free calling, automatic volume allows the device to adjust the volume level based on the background noise in the vehicle (page 10).

Automatic volume control lowers the volume of the device when background noise is low and raises the volume level when background noise increases.

Enabling Automatic Volume

Your device can increase or decrease the volume automatically based on the level of background noise.

- Select Volume > ¹/₃.
- 2 If necessary, select Automatic Volume.
- 3 Select Enabled.

Status Bar Icons

The status bar is located at the top of the main menu. The status bar icons display information about features on the device. You can select some icons to change settings or view additional information.

	GPS signal status	
*	Bluetooth $^{\textcircled{B}}$ technology status (appears when Bluetooth is enabled)	
	Transportation mode indicator	
9:10 A	Current time	
•	Battery status	
光	Connected to Smartphone Link	
53°F	Temperature	

Viewing GPS Signal Status

Hold **Hold** for three seconds.

Battery Information

After the device is connected to power, it begins to charge.

In the status bar indicates the status of the internal battery. To increase the accuracy of the battery gauge, you should fully discharge the battery and then fully charge it. Do not unplug the device until it is fully charged.

Setting the Time

- 1 From the status bar, select the time.
- 2 Select an option:
 - To set the time automatically using GPS information, select Automatic.
 - To set the time manually, drag the numbers up or down.

Using the On-Screen Buttons

- Select Storeturn to the previous menu screen.
- Hold **5** to quickly return to the main menu.
- Select **♦** or **♦** to see more choices.
- Hold **♦** or **♦** to scroll faster.
- Select to see a menu of options for the current screen.

Using the On-Screen Keyboard

See "Language and Keyboard Settings" to change the keyboard layout (page 14).

- Select @ to change the keyboard language mode.
- Select &?% to enter special characters, such as punctuation marks.

Using a Backup Camera

Keep your eyes and mind on driving while using the backup camera. Using a backup camera is an enhancement for safety practices. The backup camera is not a replacement for driver attentiveness and good judgment.

If a composite video backup camera has been installed in your vehicle, you can view the output of the camera on your device.

1 If necessary, connect the camera to the video-in jack ① on the mount.



- 2 Select an option:
 - If your camera is connected to your reverse lights, put your vehicle in reverse.
 - If your camera is connected to the vehicle battery, select on the screen.

The camera output appears on the device screen.

Locations

The detailed maps loaded in your device contain locations, such as restaurants, hotels, auto services, and detailed street information. You can use categories to browse for nearby businesses and attractions. You can also search for addresses, coordinates, cities, and intersections.

Finding Locations

Finding a Location by Category

- 1 Select Where To?.
- 2 Select a category, or select Categories.
- **3** If necessary, select a subcategory.
- 4 Select a location.

Searching Within a Category

After you have performed a search for a point of interest, certain categories may display a Quick Search list that shows the last three destinations you selected.

- 1 Select Where To?.
- 2 Select a category, or select Categories.
- 3 Select a category.
- 4 If applicable, select a destination from the Quick Search list.



5 If necessary, select the appropriate destination.

Finding RV Services

NOTE: This feature is not available in all areas.

You can find nearby locations that offer repair, towing, and other services for RVs.

Select Where To? > RV Services.

Finding RV Parks

NOTE: This feature is not available in all areas.

You can search for RV parks based on the amenities available.

- 1 Select Where To? > RV Parks.
- 2 If necessary, select **Select to filter by amenities**, select one or more amenities, and select **Save**.
- 3 Select a location.

Finding ACSI™ Campsites

NOTE: This feature is not available in all areas.

You can search for Auto Camper Service International (ACSI) campsites based on the amenities available.

- 1 Select Where To? > ACSI.
- 2 If necessary, select **Select to filter by amenities**, select one or more amenities, and select **Save**.
- 3 Select a location.

Finding MHF Campgrounds and Camper Parking

NOTE: This feature is not available in all areas.

You can search for Motorhome Facts (MHF) campgrounds and camper parking.

1 Select Where To? > MHF.

- 2 Select an option:
 - To search the entire database, select All Categories.

- To limit your search to campgrounds, select **Campgrounds**.
- To limit your search to camper parking, select **Camper** parking.
- To use the spell search feature, select ____.
- 3 Select a location.

Finding a Location Using the Search Bar

You can use the search bar to search for locations by entering a category, brand name, address, or city name.

- 1 Select Where To?.
- 2 Select Enter Search in the search bar.
- 3 Enter all or part of the search term.

Suggested search terms appear below the search bar.

- 4 Select an option:
 - To search for a type of business, enter a category name (for example, "movie theaters").
 - To search for a business name, enter all or part of the name.
 - To search for an address near you, enter the street number and street name.
 - To search for an address in another city, enter the street number, street name, city, and state.
 - · To search for a city, enter the city and state.
 - To search for coordinates, enter latitude and longitude coordinates.
- 5 Select an option:
 - To search using a suggested search term, select the term.
 - To search using the text you entered, select Q.
- 6 If necessary, select a location.

Changing the Search Area

- 1 From the main menu, select Where To?.
- 2 Select Searching Near.
- 3 Select an option.

Finding a Location by Browsing the Map

Before you can find places included in the map data, such as restaurants, hospitals, and fuel stations, you must enable the map layer for places along the road (page 7).

- 1 Select View Map.
- 2 Drag and zoom the map to display the area to search.
- **3** If necessary, select **Q**, and select a category icon to view only a specific category of places.
 - Location markers (III or a blue dot) appear on the map.
- 4 Select an option:
 - Select a location marker.
 - Select a point, such as a street, intersection, or address location.
- **5** If necessary, select the location description to view additional information.

Finding an Address

NOTE: The order of the steps may change depending on the map data loaded on your device.

- 1 Select Where To? > Address.
- 2 Enter the address number, and select Done.
- 3 Enter the street name, and select Next.
- 4 If necessary, select **Searching Near** to change the city, state, or province.
- 5 If necessary, select the city, the state, or the province.

6 If necessary, select the address.

Finding Recently Found Destinations

Your device stores the last 50 destinations you have found.

- 1 Select Where To? > Recent.
- 2 Select a location.

Finding Parking

- 1 Select Where To? > Categories > Parking.
- **2** Select a parking location.

Search Tools

Search tools allow you to search for specific types of locations by responding to on-screen prompts.

Finding an Intersection

1 Select Where To? > Categories > Intersections.

- **2** Select an option:
 - Select a state or province.
 - To change the country, state, or province, select **State or Country**, and enter a name.
- 3 Enter the first street name, and select Next.
- 4 If necessary, select the street.
- 5 Enter the second street name, and select Next.
- 6 If necessary, select the street.
- 7 If necessary, select the intersection.

Finding a City

- 1 Select Where To? > Categories > Cities.
- 2 Select Enter Search.
- **3** Enter a city name, and select **Q**.
- 4 Select a city.

Finding a Location Using Coordinates

You can find a location using latitude and longitude coordinates. This can be helpful when geocaching.

1 Select Where To? > Categories > Coordinates.

- 2 If necessary, select ****, and change the coordinate format or datum.
- 3 Select the latitude coordinate.
- 4 Enter the new coordinate, and select Done.
- **5** Select the longitude coordinate.
- 6 Enter the new coordinate, and select Done.
- 7 Select View on Map.

Saving Locations

Saving a Location

- 1 Search for a location (page 3).
- **2** From the search results, select a location.
- 3 Select 1.
- 4 Select = > Save.
- 5 If necessary, enter a name, and select Done.

Saving Your Current Location

- 1 From the map, select the vehicle icon.
- 2 Select Save.
- 3 Enter a name, and select Done.
- 4 Select OK.

Saving a Home Location

You can set your home location for the location you return to most often.

- 1 Select Where To? > = > Set Home Location.
- 2 Select Enter My Address, Use Current Location, or Recently Found.

The location is saved as "Home" in the Saved menu.

Going Home

Select Where To? > Go Home.

Editing Your Home Location Information

- 1 Select Where To? > Saved > Home.
- 2 Select 1.
- 3 Select > Edit.
- 4 Enter your changes.
- 5 Select Done.

Editing a Saved Location

- 1 Select Where To? > Saved.
- 2 If necessary, select a category.
- 3 Select a location.
- 4 Select 1
- 5 Select = > Edit.
- 6 Select an option:
 - Select Name.
 - Select Phone Number.
 - Select **Categories** to assign categories to the saved location.
 - Select **Change Map Symbol** to change the symbol used to mark the saved location on a map.
- 7 Edit the information.
- 8 Select Done.

Assigning Categories to a Saved Location

You can add custom categories to organize your saved locations.

NOTE: Categories appear in the saved locations menu after you have saved at least 12 locations.

- 1 Select Where To? > Saved.
- 2 Select a location.
- 3 Select 1
- 4 Select > Edit > Categories.
- 5 Enter one or more category names, separated by commas.
- 6 If necessary, select a suggested category.
- 7 Select Done.

Deleting a Saved Location

NOTE: Deleted locations cannot be recovered.

- 1 Select Where To? > Saved.
- 2 Select = > Delete Saved Places.
- 3 Select the box next to the saved locations to delete, and select **Delete**.

Setting a Simulated Location

If you are indoors or not receiving satellite signals, you can use the GPS to set a simulated location.

- 1 Select Settings > Navigation > GPS Simulator.
- 2 From the main menu, select View Map.
- 3 Tap the map twice to select an area. The address of the location appears at the bottom of the screen.

- **4** Select the location description.
- 5 Select Set Location.

Adding a Shortcut

You can add shortcuts to the Where To? menu. A shortcut can point to a location, a category, or a search tool.

The Where To? menu can contain up to 36 shortcut icons.

- 1 Select Where To? > Add Shortcut.
- 2 Select an item.

Removing a Shortcut

- 1 Select Where To? > > > Remove Shortcut(s).
- 2 Select the shortcut to remove.
- **3** Select the shortcut again to confirm.

Custom Points of Interest

Custom POIs are customized points on the map. They can contain alerts that let you know if you are near a designated point or if you are traveling faster than a specified speed.

Installing POI Loader

You can create or download custom POI lists on your computer and install them on your device using POI Loader software.

- 1 Go to www.garmin.com/poiloader.
- **2** Follow the on-screen instructions.

Using the POI Loader Help Files

For more information on the POI loader, refer to the Help file. With the POI loader open, click **Help**.

Finding Custom POIs

Before you can find custom POIs, you must load custom POIs on your device using the POI Loader software (page 5).

- 1 Select Where To? > Categories.
- 2 Scroll to the Other Categories section, and select a category.

Navigation

Transportation Modes

Routing and navigation are calculated differently based on your transportation mode. The current transportation mode is indicated by an icon in the status bar.

	RV mode
	Automobile mode

Choosing a Transportation Mode

Select 🕰 .

Starting a Route

- 1 Search for a location (page 3).
- 2 Select a location.
- 3 Select Go!.

Previewing Multiple Routes

- 1 Search for a location (page 3).
- 2 From the search results, select a location.
- 3 Select Routes.
- 4 Select a route.

Changing the Route Calculation Mode

The route calculation is based on road speeds and vehicle acceleration data for a given route. The calculation mode affects only automobile routes.

Select Settings > Navigation > Calculation Mode.

- Select **Faster Time** to calculate routes that are faster to drive but can be longer in distance.
- Select Shorter Distance to calculate routes that are shorter in distance but can take more time to drive.
- Select Off Road to calculate point-to-point routes (without roads).

Navigating Off Road

If you are not following roadways as you navigate, you can use Off Road mode.

- 1 Select Settings > Navigation.
- 2 Select Calculation Mode > Off Road > Save.
 - The next route will be calculated as a straight line to the location.

Starting a Route to a Saved Location

- 1 Select Where To? > Saved.
- 2 If necessary, select a category, or select All Saved Places.
- 3 Select a location.
- 4 Select Go!.

Your Route on the Map

NOTICE

The speed limit feature is for information only and does not replace your responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations you receive for failing to follow all applicable traffic laws and signs.

The route is marked with a magenta line. A checkered flag marks your destination.

As you travel, the device guides you to the destination with voice prompts, arrows on the map, and directions at the top of the map. If you depart from the original route, the device recalculates the route and provides new directions.

A data field displaying the current speed limit may appear as you travel on major roadways.



Using the Navigation Map

- 1 Select View Map.
- 2 Select anywhere on the map.
- 3 Select an option:
 - To zoom in or out, select + or -.
 - To switch between North Up and 3-D views, select ▲.
 - To view specific categories when not navigating a route, select Q.
 - To center the map on your current location, select 5.

Adding a Point to a Route

Before you can add a stop, you must be navigating a route.

- 1 From the map, select **→** > Where To?.
- 2 Search for the extra stop.
- 3 Select the stop from the search results.
- 4 Select Go!.

5 Select Add to Active Route.

Taking a Detour

Before you can take a detour, you must add the detour tool to the map tools menu (page 7).

You can take a detour for a specified distance along your route or detour around specific roads. This is useful if you encounter construction zones, closed roads, or poor road conditions.

- 1 While navigating a route, from the map select \equiv > **Detour**.
- 2 Select an option.
 - To detour your route for a specific distance, select **0.5 mi**, **2 mi**, or **5 mi**.
 - To detour around a specific road on the route, select .
- 3 If necessary, select a road to detour around.

Stopping the Route

From the map, select $\equiv > \otimes$.

Viewing Route Activity

Viewing a List of Turns

While navigating a route, you can view all of the turns and maneuvers for your entire route and the distance between turns.

- 1 While navigating a route, select the text bar on the top of the map.
- 2 Select a turn.

The details for the turn appear. If available, an image of the junction appears for junctions on major roadways.

Viewing the Entire Route on the Map

- **1** While navigating a route, select the navigation bar at the top of the map.
- 2 Select > Map.

Viewing the Next Turn

While navigating an automobile route, a preview of the next turn, lane change, or other maneuver appears in the upper-left corner of the map.

The preview includes the distance to the turn or maneuver and the lane in which you should be traveling, if available.

From the map, select **Pos** to view the next turn on the map.

Active Lane Guidance

As you approach a turn while navigating a route, a detailed simulation of the road appears beside the map, if available. A colored line indicates the proper lane for the turn.

Viewing Junctions

While navigating a route, you can view the junctions on major roadways. When you approach a junction in a route, the image of that junction appears briefly, if available.

From the map, select proven to view the junction, if available.

Warning Icons

<u> WARNING</u>

Entering your vehicle profile characteristics does not guarantee that your vehicle's characteristics will be accounted for in all route suggestions or that you will receive the warning icons in all cases. Limitations may exist in the map data such that your device cannot account for these restrictions or road conditions in all cases. Always defer to all posted road signs and road conditions when making driving decisions.

Road Condition Warnings

	Risk of Grounding
≋	Lateral Wind

X	Narrow Road
\$	Sharp Curve
.L	Steep Down Hill
辛	Tree Overhang

About Up Ahead

You can view upcoming businesses and services along your route or the road on which you are traveling.

Services are listed under tabs by category.

	Gas
Ψ٩	Food
إنعر	Lodging
∔†	Restrooms
Ρ	Parking
\$	Banks and ATMs

Finding Upcoming Points of Interest

1 From the map, select \equiv > **Up Ahead**.

- 2 Select a tab.
- 3 Select a point of interest.

Customizing the Up Ahead Categories

You can change the categories you search for, rearrange the order of the categories, and search for a specific business or category.

- 1 From the map, select **> Up Ahead**.
- **2** Select a service icon.
- 3 Select 1.
- 4 Select an option:
 - To move the a category up or down in the list, select and drag the arrow to the right of the category name.
 - To change a category, select the category.
 - To create a custom category, select a category, select Custom Search, and enter the name of a business or category.
- 5 Select Done.

Trip Information

Viewing Trip Data from the Map

Before you can view trip data on the map, you must add the tool to the map tools menu (page 7).

From the map, select **=** > **Trip Data**.

Customizing the Trip Data Fields

Before you can customize the data that appears in the trip data fields on the map, you must add the Trip Data tool to the map tools menu (page 7).

- 1 Select View Map.
- 2 Select > Trip Data.
- 3 Select a trip data field.
- 4 Select an option.

The new trip data field appears in the trip data list.

Viewing the Trip Information Page

The trip information page displays your present speed and provides statistics about your trip.

NOTE: If you make frequent stops, leave the device turned on, so it can accurately measure elapsed time during the trip.

From the map, select Speed.

≡			
♤	Trip A 000054 <mark>0</mark> で	29₩	тгір В 000054 <mark>0</mark> Т
ŧ	Arrive In 0:39	Arrive In 40۳	Turn In 0:13
5	Turn In 15¶	Max. Speed	Moving Avg. 34۳

Viewing the Trip Log

Your device keeps a trip log, which is a record of the path you have traveled.

- 1 Select Settings > Map & Vehicle > Map Layers.
- 2 Select the Trip Log check box.

Resetting Trip Information

- 1 From the map, select **Speed**.
- 2 Select => Reset Field(s).
- 3 Select an option:
 - When not navigating a route, select **Select All** to reset every data field except the speedometer, on the first page.
 - Select **Reset Trip Data** to reset the information on the trip computer.
 - Select Reset Max. Speed to reset the maximum speed.
 - Select Reset Trip B to reset the odometer.

Using Suggested Routes

Before you can use this feature, you must save at least one location and enable the travel history feature (page 14).

Using the myTrends[™] feature, your device predicts your destination based on your travel history, the day of the week, and the time of day. After you have driven to a saved location several times, the location may appear in the navigation bar on the map, along with the estimated time of travel, and traffic information.

Select the navigation bar to view a suggested route to the location.

Viewing Current Location Information

You can use the Where Am I? page to view information about your current location. This feature is helpful if you need to tell emergency personnel your location.

From the map, select the vehicle.

Finding Nearby Services

You can use the Where Am I? page to find nearby services, such as fuel, hospitals or police stations.

- 1 From the map, select the vehicle.
- 2 Select a category.

Getting Directions to Your Current Location

If you need to tell another person how to get to your current location, your device can give you a list of directions.

- 1 From the map, select the vehicle.
- 2 Select = > Directions to Me.
- 3 Select a starting location.
- 4 Select Select.

Avoiding Road Features

- 1 Select Settings > Navigation > Avoidances.
- 2 Select the road features to avoid on your routes, and select **Save**.

About Custom Avoidances

Custom avoidances allow you to avoid specific areas and sections of road. You can enable and disable custom avoidances as needed.

Avoiding an Area

- 1 Select Settings > Navigation > Custom Avoidances.
- 2 If necessary, select Add Avoidances.
- 3 Select Add Avoid Area.
- 4 Select the upper-left corner of the area to avoid, and select **Next**.
- 5 Select the lower-right corner of the area to avoid, and select **Next**.

The selected area is shaded on the map.

6 Select Done.

Avoiding a Road

- 1 Select Settings > Navigation > Custom Avoidances.
- 2 Select Add Avoid Road.
- 3 Select the starting point of the section of road to avoid, and select Next.
- 4 Select the ending point of the road section, and select Next.
- 5 Select Done.

Disabling a Custom Avoidance

You can disable a custom avoidance without deleting it.

- 1 Select Settings > Navigation > Custom Avoidances.
- 2 Select an avoidance.
- 3 Select > Disable.

Deleting Custom Avoidances

1 Select Settings > Navigation > Custom Avoidances.

- 2 Select an option:
 - To delete all custom avoidances, select x̄.
 - To delete one custom avoidance, select the avoidance, and select > Delete.

Customizing the Map

Customizing the Map Tools

You can select the shortcuts that appear in the map tools menu.

- 1 Select Settings > Map & Vehicle > Map Tools.
- 2 Select the map tools to include in the menu.
- 3 Select Save.

Customizing the Map Layers

You can customize which data appear on the map, such as icons for points of interest and road conditions.

- 1 Select Settings > Map & Vehicle > Map Layers.
- 2 Select the layers to include on the map, and select Save.

Changing the Map Data Field

- 1 From the map, select a data field.
- NOTE: You cannot customize Speed.
- 2 Select a type of data to display.
- 3 Select Save.

Changing the Map Perspective

- 1 Select Settings > Map & Vehicle > Driving Map View.
- **2** Select an option:
 - Select **Track Up** to display the map in two dimensions (2-D), with your direction of travel at the top.
 - Select North Up to display the map in 2-D with north at the top.

• Select 3-D to display the map in three dimensions.

Safety Cameras

NOTICE

Garmin is not responsible for the accuracy of or the consequences of using a custom point of interest or a safety camera database.

Safety camera information is available in some locations. Check www.garmin.com/safetycameras for availability. For these locations, you can purchase a subscription for safety camera information. The subscription includes the locations of hundreds of safety cameras. Your device alerts you when you are approaching a safety camera and can warn you if you are driving too fast. The data is updated at least weekly, so you can update your device regularly to receive the most up-to-date information.

You can purchase a new region or extend an existing subscription at any time. Each region that you purchase has an expiration date.

Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Traffic information may not be available in all areas or countries. For information about traffic receivers and coverage areas, go to www.garmin.com/traffic.

A traffic receiver is included in some packages, built into either the vehicle power cable or the device, and is an optional accessory for all models.

- Traffic alerts appear on the map when there are traffic incidents along your route or in your area.
- You can receive traffic information through a traffic receiver or as a subscription service through Smartphone Link (page 11).
- The device must be connected to Smartphone Link with an active traffic subscription to receive traffic information through Smartphone Link.
- The device must be connected to vehicle power to receive traffic information through a traffic receiver.
- The powered traffic receiver and the device may need to be in data range of a station transmitting traffic data to receive traffic information.
- You do not need to activate the subscription included with your device or traffic receiver.
- If your device includes an external traffic antenna, you should always leave the external antenna plugged in for the best traffic reception.

Receiving Traffic Data Using a Traffic Receiver

NOTICE

Heated (metallized) windshields could degrade the performance of the traffic receiver.

Before you can receive traffic data using a traffic receiver, you must have a traffic-compatible power cable. If your device model includes lifetime traffic, you should use the vehicle power cable packaged with your device. If your device model does not include traffic, you must purchase a Garmin traffic receiver accessory. Go to www.garmin.com/traffic for more information.

Your device can receive traffic signals from a station broadcasting traffic data.

NOTE: In some areas, traffic information may be received from FM radio stations using HD Radio[™] technology.

- 1 Connect the traffic-compatible power cable to an external power source.
- **2** Connect the traffic-compatible power cable to the device.

When you are within a traffic coverage area, your device displays traffic information.

Traffic Receiver



1	Mini-USB connector
2	External antenna connector
3	Internal antenna
4	Power LED
5	Vehicle power adapter

Positioning the Traffic Receiver

You can position the traffic receiver power cable for optimal traffic reception.

- 1 Uncoil the cable.
- 2 Place the middle of the cable in a location with an unobstructed view of the sky, such as the dash.

NOTE: Do not rest the cable on the cable plug that connects to the vehicle power source.

Do not place the cable on the floor or underneath other objects.

Viewing Upcoming Traffic

You can view traffic incidents coming up along your route or along the road on which you are traveling.

1 While navigating a route, select \equiv > **Traffic**.

The nearest upcoming traffic incident appears in a panel on the right side of the map.

2 Select the traffic incident to view additional details.

Viewing Traffic on the Map

The traffic map shows color-coded traffic flow and delays on nearby roads.

- 1 From the main menu, select Apps > Traffic.

Searching for Traffic Incidents

- 1 From the main menu, select **Apps > Traffic**.
- 2 Select = > Incidents.
- 3 Select an item in the list.
- 4 If there is more than one incident, use the arrows to view additional incidents.

Traffic on Your Route

When a traffic delay occurs on your route, an alert appears on the map, and the device calculates an alternate route to avoid the delay. You can choose whether to use alternate routes automatically, or upon request. See Traffic Settings for more information (page 14). Your device may route you through a traffic delay if a better alternative route does not exist. The delay time is added into your estimated time of arrival automatically.

Taking an Alternate Route

If you do not have your device set to use alternate routes automatically, you can manually start an alternate route to avoid a traffic delay.

- 1 While navigating a route, select \equiv > **Traffic**.
- 2 Select Alternate Route.

NOTE: If a better alternative route does not exist, this option is not available, and **On Fastest Route** appears instead.

3 Select Go!.

About Traffic Cameras

Traffic cameras provide live images of traffic conditions on major roadways and intersections. You can save cameras that you want to view regularly.

Saving a Traffic Camera

Before you can use this feature, you must subscribe to the photoLive service, and your device must be connected to a supported phone running Smartphone Link (page 11).

This feature is not available in all areas.

- 1 Select Apps > photoLive.
- 2 Select Touch to Add.
- 3 Select a road.
- 4 Select an intersection.
- 5 Select Touch to Add.

Viewing a Traffic Camera

Before you can view a traffic camera, you must save a traffic camera (page 9).

- 1 Select Apps > photoLive.
- **2** Select a camera.

About Traffic Subscriptions

You can purchase additional subscriptions or a renewal if your subscription expires. Go to http://www.garmin.com/traffic.

Subscription Activation

You do not need to activate the subscription included with your FM traffic receiver. The subscription activates automatically after your device acquires satellite signals while receiving traffic signals from the pay service provider.

Viewing Traffic Subscriptions

Select Settings > Traffic > Subscriptions.

Adding a Subscription

You can purchase traffic subscriptions for other regions or countries.

- 1 From the main menu, select Traffic.
- 2 Select Subscriptions > +.
- 3 Write down the FM traffic receiver unit ID.
- **4** Go to www.garmin.com/fmtraffic to purchase a subscription and get a 25-character code.

The traffic subscription code cannot be reused. You must obtain a new code each time you renew your service. If you own multiple FM traffic receivers, you must obtain a new code for each receiver.

- 5 Select Next on the device.
- 6 Enter the code.
- 7 Select Done.

trafficTrends[™]

When the trafficTrends feature is enabled, your device uses historic traffic data to calculate more-efficient routes.

NOTE: Different routes may be calculated based on traffic trends for the day of the week or the time of day.

Disabling trafficTrends

To prevent your device from recording or sharing traffic data, you must disable trafficTrends.

Select Settings > Traffic > trafficTrends.

Enabling Traffic

You can enable or disable traffic data. When traffic data is disabled, the device does not receive traffic data, but it still avoids potentially congested areas in routes using the trafficTrends feature, if enabled (page 9).

- 1 Select Settings > Traffic.
- 2 Select the **Traffic** check box.

Voice Command

NOTE: Voice command is not available for all languages and regions, and may not be available on all models.

NOTE: Voice Activated Navigation may not achieve desired performance when in a noisy environment.

Voice command allows you to use your device by saying words and commands. The voice command menu provides voice prompts and a list of available commands.

Setting the Wakeup Phrase

The wakeup phrase is a word or phrase you can say to activate voice command. The default wakeup phrase is **Voice Command**.

TIP: You can reduce the chance of accidental voice command activation by using a strong wakeup phrase.

- 1 Select Apps > Voice Command > Customize Phrase.
- 2 Enter a new wakeup phrase.

The device indicates the strength of the wakeup phrase as you enter the phrase.

3 Select Done.

Activating Voice Command

Say your wakeup phrase. The voice command menu appears.

Voice Command Tips

- Speak in a normal voice directed at the device.
- Reduce background noise, such as voices, or the radio, to increase the accuracy of the voice recognition.
- Speak commands as they appear on the screen.
- · Respond to voice prompts from the device as needed.
- Increase the length of your wakeup phrase to reduce the chance of accidental voice command activation.
- Listen for two tones to confirm when the device enters and exits voice command.

Starting a Route Using Voice Command

You can say the names of popular, well-known locations.

- 1 Say your wakeup phrase (page 9).
- 2 Say Find Place.
- **3** Listen for the voice prompt, and speak the name of the location.

- 4 Say the line number.
- 5 Say Navigate.

Muting Instructions

You can disable the voice prompts for voice command without muting the device.

- 1 Select Apps > Voice Command > X.
- 2 Select Mute Instructions > Enabled.

Disabling Voice Command

You can disable voice command, which prevents you from accidentally activating voice command while speaking.

- 1 Select Apps > Voice Command > ****.
- 2 Select Voice Command > Disabled.

Hands-Free Phone Calls

About Hands-Free Calling

NOTE: Bluetooth wireless technology is not available on all models, or for all languages and regions.

Hands-free calling is available on some models. Using Bluetooth wireless technology, your device can connect to your mobile phone to become a hands-free device. To determine whether your mobile phone with Bluetooth technology is compatible with your device, go to www.garmin.com/bluetooth.

Your phone may not support all of the hands-free phone features your device provides.

Enabling Bluetooth Wireless Technology

- 1 Select Settings > Bluetooth.
- 2 Select Bluetooth.

Pairing Your Phone

Before you can use hands-free calling, you must pair your device with a compatible mobile phone.

- 1 Place your phone and your Bluetooth device within 33 ft. (10 m) of each other.
- **2** On your device, enable Bluetooth wireless technology.
- 3 Select an option:
 - Select Settings > Bluetooth > Add Phone.
 - If you have already paired a different phone, select Settings > Bluetooth > Phone > ↓.
- **4** On your phone, enable Bluetooth wireless technology.
- 5 On your device, select OK. A list of nearby Bluetooth devices appears.
- 6 Select your phone from the list, and select OK.
- 7 If necessary, on your phone, confirm that the device is allowed to connect.
- 8 If necessary, enter the device Bluetooth PIN into your phone.

Tips After Pairing the Devices

- After the initial pairing, the two devices can connect automatically each time you turn them on.
- When your phone is connected to your device, you are ready to receive voice calls.
- When you turn on the device, it tries to connect to the last phone to which it was connected.
- You might need to set your phone to connect to the device automatically when the device is turned on.

Disconnecting Your Phone

1 Select Settings > Bluetooth.

2 Select Phone > None > Save.

Your phone is disconnected from your device but remains paired with your device.

Deleting a Paired Phone

You can delete a paired phone to prevent it from automatically connecting to your device in the future.

- 1 Select Settings > Bluetooth > Phone.
- 2 Select 🖬
- 3 Select the phone, and select Delete.

Placing a Call

Dialing a Number

- 1 Select Apps > Phone > Dial.
- 2 Enter the number.
- 3 Select Dial.

Calling a Contact in Your Phone Book

Your phone book is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the phone book to be available. Some phones do not support this feature.

- 1 Select Apps > Phone > Phone Book.
- 2 Select a contact.
- 3 Select Call.

Calling a Location

- 1 Select Apps > Phone > Browse Categories.
- 2 Select a point of interest.
- 3 Select Call.

Receiving a Call

When you receive a call, select Answer or Ignore.

Using the Call History

Your call history is loaded from your phone to the device each time your phone and the device connect. It may take a few minutes for the call history to be available. Some phones do not support this feature.

- 1 Select Apps > Phone > Call History.
- 2 Select a category.
- A list of calls appears, with the most recent calls at the top.
- **3** Select a call.

Using In-Call Options

- 1 From the map, while on a call, select **2**.
- **2** Select an option.
 - To transfer audio to your phone, select Handset.
 TIP: You can use this feature if you want to turn off your device and remain on the call, or if you need privacy.
 TIP: You can use this feature to use automated systems.

TIP: You can use this feature to use automated systems, such as voice mail.

- To mute the microphone, select Mute.
- To hang up, select End Call.

Saving a Home Phone Number

TIP: After you save a home number, you can edit the home number by editing "Home" in your list of saved locations (page 4).

1 Select Apps > Phone > > Set Home Number.

- **2** Enter your phone number.
- 3 Select Done.

Calling Home

Before you can call home, you must enter a phone number for your home location.

Select Saved > Home > = > Call.

Using the Apps

Using Help

Select **Apps** > **Help** to view information about using the device.

Searching Help Topics

Select Apps > Help > Q.

Smartphone Link

Smartphone Link is a phone application that allows you to synchronize location data with your phone and access live information using your phone data connection. Your device transfers data from Smartphone Link using Bluetooth wireless technology. Live information is available through free and subscription-based plans from Garmin Live Services (page 11).

Saved locations and recently found locations are synchronized with your phone each time your device connects to Smartphone Link.

Downloading Smartphone Link

Smartphone Link is available for some smartphones. Go to www.garmin.com/smartphonelink or see the application store for your phone for compatibility and availability information.

Download Smartphone Link from the application store on your supported phone.

See your phone owner's manual for information on downloading and installing applications.

Connecting to Smartphone Link

Before you can connect to Smartphone Link, you must download and install the Smartphone Link application on your phone.

- **1** Start Smartphone Link on your phone.
- 2 From your device, select Settings > Bluetooth, and select the Bluetooth check box.
- 3 From your phone, select Bluetooth Settings.
- **4** From your phone, enable Bluetooth wireless technology, and scan for nearby Bluetooth devices.

See your phone owner's manual for more information.

- **5** From your phone, select your device from the list of nearby devices.
- 6 Follow the on-screen instructions on your phone and on your device to confirm the pairing request.

* appears in the status bar on your device when Smartphone Link is connected.

Sending a Location from Your Phone to Your Device

Smartphone Link is registered as a navigation application on your phone.

- 1 From your phone, select the button to start navigating to a location (see the owner's manual for your phone).
- 2 From the application menu, select **Smartphone Link**.

The next time you connect your device to your phone, the location is transferred to the recently found items on your device.

Disabling Calls While Connected to Smartphone Link

While the device is connected to the phone and receiving Garmin Live Services, you can disable hands-free calling.

- 1 Select Apps > Smartphone Link.
- 2 Select your phone.
- 3 Clear the Hands-Free Calling check box.

Garmin Live Services

Before you can use Garmin Live Services, your device must be connected to a supported phone running Smartphone Link (page 11).

Connecting to Smartphone Link provides access to Garmin Live Services. Garmin Live Services provides free and subscriptionbased plans to view live data on your device, such as traffic conditions and weather.

Some services, like weather, are available as separate apps on your device. Other services, like traffic, enhance the existing navigation features on your device. Features that require access to Garmin Live Services display the Smartphone Link symbol and appear only when the device is connected to Smartphone Link.

Subscribing to Garmin Live Services

Before you can subscribe to Garmin Live Services, you must install the Smartphone Link app on your phone.

- 1 Start the Smartphone Link app on your phone (page 11).
- 2 Select Garmin Live Services.

A list of services and subscription prices appears.

- 3 Select a service.
- 4 Select the price.
- 5 Select Subscribe.
- 6 Follow the on-screen instructions.

Finding Your Last Parking Spot

When you disconnect the device from vehicle power while the device is on, your current location is saved as a parking spot.

Select **Apps** > **Last Spot**.

About ecoRoute

In some areas, before you can use ecoRoute[™] features, you must purchase an unlock code or an ecoRoute HD accessory. Go to www.garmin.com/ecoroute for more information.

The ecoRoute feature calculates the fuel economy and the fuel price of navigating to a destination, and offers tools for improving fuel efficiency.

The data provided by the ecoRoute feature is an estimate only. The data is not actually read from the vehicle, unless you are using the ecoRoute HD accessory.

To receive more-accurate fuel reports for your specific vehicle and driving habits, calibrate the fuel economy (page 12).

ecoRoute HD Accessory

When connected to the ecoRoute HD accessory, your device can receive real-time vehicle information, such as error messages, RPM, and battery voltage. Your device includes data read from the vehicle by the ecoRoute HD accessory when calculating ecoRoute data.

The ecoRoute HD accessory is compatible only with devices that have Bluetooth wireless technology.

Go to www.garmin.com/ecoRoute.

Setting Up the Vehicle

The first time you use the ecoRoute features, you must enter vehicle information.

- 1 Select Apps > ecoRoute.
- **2** Follow the on-screen instructions.

Changing the Fuel Price

- 1 Select Apps > ecoRoute > At the Pump.
- 2 Enter the current price of fuel, and select Next.
- 3 Select Yes.

Calibrating the Fuel Economy

You can calibrate the fuel economy to receive more-accurate fuel reports for your specific vehicle and driving habits. You should calibrate when you fill up your fuel tank.

1 Select Apps > ecoRoute > At the Pump.

- 2 Enter the current fuel price.
- **3** Enter the amount of fuel the vehicle has used since the last time the fuel tank was filled.
- 4 Enter the distance you have traveled since the last time the fuel tank was filled.
- 5 Select Next.
 - The device calculates the average vehicle fuel economy.
- 6 Select Save.

About ecoChallenge

ecoChallenge helps you maximize the vehicle fuel economy by scoring your driving habits. The higher your ecoChallenge scores, the more fuel you have saved. The ecoChallenge collects data and calculates a score whenever your device is moving and in Automobile transportation mode.

Viewing ecoChallenge Scores

Select Apps > ecoRoute > ecoChallenge.

About the ecoChallenge Score

- Acceleration: Displays your score for smooth and gradual acceleration. You lose points for rapid acceleration.
- **Braking**: Displays your score for smooth and gradual braking. You lose points for hard braking.
- **Overall**: Displays an average of the speed, acceleration, and braking score.
- **Speed**: Displays your score for driving your vehicle at the optimal speed for conserving fuel.

Resetting the ecoChallenge Scores

1 Select Apps > ecoRoute > ecoChallenge.

2 Select = > Reset.

Viewing Fuel Economy Information

- 1 Select Apps > ecoRoute > Fuel Economy.
- 2 Select a section of the graph to zoom in.

Mileage Reports

Mileage reports provide the distance, the time, the average fuel economy, and the fuel cost of navigating to a destination.

A mileage report is created for every route that you drive. If you stop a route on your device, a mileage report is created for the distance you traveled.

Viewing a Mileage Report

You can view saved mileage reports on the device.

TIP: You can connect the device to your computer and access mileage reports in the Reports folder on the device.

- 1 Select Apps > ecoRoute > Mileage Report.
- 2 Select a report.

Resetting ecoRoute Information

- 1 Select Apps > ecoRoute > Vehicle Profile.
- 2 Select = > Reset.

Viewing myGarmin Messages

Before you can use this feature, your device must be connected to a supported phone running Smartphone Link (page 11). This feature is not available in all areas.

You can view messages from myGarmin, such as notifications for software and map updates.

1 Select Apps > myGarmin.

If you have unread messages, the number of unread messages appears on the myGarmin icon.

2 Select a message subject. The full message appears.

Viewing the Weather Forecast

Before you can use this feature, your device must be connected to a supported phone running Smartphone Link (page 11). This feature is not available in all areas.

- 1 Select Apps > Weather.
- **2** Select a day.

The detailed forecast for that day appears.

Viewing Weather Near a Different City

- 1 Select Apps > Weather > Current Location.
- 2 Select an option:
 - To view weather for a favorite city, select a city in the list.
 - To add a favorite city, select Add City, and enter a city name.

Viewing the Weather Radar

You can view an animated, color-coded radar map of current weather conditions, as well as a weather icon on the map. The weather icon changes to show weather in the vicinity, such as rain, snow, and thunderstorms.

- 1 Select Apps > Weather.
- **2** If necessary, select a city.
- 3 Select > Weather Radar.

Viewing Weather Alerts

While you are traveling with your device, weather alerts may appear on the map. You can also view a map of weather alerts near your current location or near a selected city.

- 1 Select Apps > Weather.
- 2 If necessary, select a city.
- 3 Select **> Weather Alerts**.

Checking Road Conditions

- 1 Select Apps > Weather.
- 2 If necessary, select a city.
- 3 Select **> Road Conditions**.

Planning a Trip

You can use the trip planner to create and save a trip with multiple destinations.

- 1 Select Apps > Trip Planner.
- 2 Select New Trip.
- 3 Select Select Start Location.
- 4 Search for a location (page 3).
- 5 Select Select.
- 7 Select Next.
- 8 Enter a name, and select Done.

Scheduling a Trip

You can use the trip planner to create and save a trip with multiple destinations.

1 Select Apps > Trip Planner.

- Select a trip.
- 3 Select a location.
- 4 Select an option:
 - Select Departure Time.
 - Select Arrival Time.
- 5 Select a date and time, and select Save.
- 6 Select Duration.
- 7 Select the amount of time you will spend at the location, and select **Save**.
- 8 If necessary, repeat steps 3–7 for each location.

Navigating to a Saved Trip

- 1 Select Apps > Trip Planner.
- 2 Select a saved trip.
- 3 Select Go!.
- 4 If prompted, select a route (page 5).

Editing a Saved Trip

- 1 Select Apps > Trip Planner.
- 2 Select a saved trip.
- 3 Select .
- 4 Select an option:
 - · Select Rename Trip.
 - Select **Edit Destinations** to add and delete a location, or to change the order of locations.
 - · Select Delete Trip.
 - Select **Optimize Order** to arrange the stops on your trip in the most-efficient order.

Viewing Previous Routes and Destinations

Before you can use this feature, you must enable the travel history feature (page 14).

You can view your previous routes and places you have stopped on the map.

Select Apps > Where I've Been.

Data Management

You can store files on your device. The device has a memory card slot for additional data storage.

NOTE: The device is not compatible with Windows[®] 95, 98, Me, Windows $NT^{\mbox{$\mathbb{R}$}}$, and $Mac^{\mbox{$\mathbb{R}$}}$ OS 10.3 and earlier.

File Types

The device supports these file types.

- Maps and GPX waypoint files from myGarmin[™] mapping software, including MapSource[®], BaseCamp[™], and HomePort[™] (page 5).
- GPI custom POI files from Garmin POI Loader (page 5).

About Memory Cards

You can purchase memory cards from an electronics supplier, or purchase pre-loaded Garmin mapping software (www.garmin.com/trip_planning). In addition to map and data storage, the memory card can be used to store files such as maps, images, geocaches, routes, waypoints, and custom POIs.

Installing a Memory Card

The device supports microSD[™] and microSDHC memory cards.

- 1 Insert a memory card into the slot on the device.
- **2** Press it in until it clicks.

Connecting the Device to Your Computer

You can connect the device to your computer using the USB cable included with your device.

- 1 Plug the small end of the USB cable into the port on the device.
- 2 Plug the larger end of the USB cable into a port on your computer.

A picture of your device connected to a computer appears on the device screen.

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

Transferring Data From Your Computer

1 Connect the device to your computer (page 13).

Depending on your computer operating system, the device appears as either a portable device, a removable drive, or a removable volume.

- 2 On your computer, open the file browser.
- 3 Select a file.
- 4 Select Edit > Copy.
- 5 Browse to a folder on the device.NOTE: For a removable drive or volume, you should not place files in the Garmin folder.
- 6 Select Edit > Paste.

Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows computer as a portable device, it is not necessary to safely disconnect.

1 Complete an action:

- For Windows computers, select the **Safely Remove** Hardware icon in the system tray, and select your device.
- For Mac computers, drag the volume icon to the trash.
- **2** Disconnect the cable from your computer.

Customizing the Device

Map and Vehicle Settings

To open the Map and Vehicle settings, from the main menu, select **Settings > Map & Vehicle**.

- Vehicle: Changes the icon to represent your position on the map. Go to www.garmingarage.com for more icons.
- **Driving Map View**: Sets the perspective on the map.
- Map Detail: Sets the level of detail on the map. More detail may cause the map to draw slower.
- Map Theme: Changes the color of the map data.
- Map Tools: Selects the shortcuts that appear in the map tools menu.
- Map Layers: Sets the data that appears on the map page (page 7).
- myMaps: Sets which installed maps the device uses.

Enabling Maps

You can enable map products installed on your device.

TIP: To purchase additional map products, go to www.garmin.com/us/maps.

- 1 Select Settings > Map & Vehicle > myMaps.
- 2 Select a map.

Editing an RV Profile

You can change the vehicle weight, vehicle dimensions, and alert preferences.

- 1 Select Settings > RV Profile > RV.
- 2 Select a profile.
- 3 Select = > Edit.
- 4 Select a field to edit it.

Navigation Settings

To open the Navigation settings page, from the main menu, select **Settings > Navigation**.

Calculation Mode: Sets route preference.

Avoidances: Sets road features to avoid on a route.

- Custom Avoidances: Allows you to avoid specific roads or areas.
- **Environmental Zones**: Sets the avoidance preferences for areas with environmental or emissions restrictions that may apply to your vehicle.
- Safe Mode: Disables all functions that require significant operator attention and could become a distraction while driving.
- **GPS Simulator**: Stops the device from receiving a GPS signal, and saves battery power.

Route Preferences

To open the Calculation Mode settings page, from the main menu, select **Settings > Navigation > Calculation Mode**.

The route calculation is based on road speeds and vehicle acceleration data for a given route.

- Faster Time: Calculates routes that are faster to drive but can be longer in distance.
- **Shorter Distance**: Calculates routes that are shorter in distance but can take more time to drive.
- Less Fuel: Calculates routes that could use less fuel than other routes.
- **Off Road**: Calculates a direct line from your location to your destination.

Display Settings

To open the Display settings page, from the main menu, select **Settings > Display**.

- **Color Mode**: Changes the brightness of the screen. Decreasing the brightness can save battery power.
- **Display Timeout**: Sets the amount of idle time before your device enters sleep mode.

Brightness: Adjusts the display brightness.

Screenshot: Allows you to take a picture of the device screen. Screenshots are saved in the Screenshot folder of the device storage.

Bluetooth Settings

To open the Bluetooth settings, from the main menu, select **Settings > Bluetooth**.

Bluetooth: Enables Bluetooth wireless technology.

- Add Phone: Manages connection between your device and wireless headsets with Bluetooth wireless technology.
- Friendly Name: Allows you to enter a friendly name that identifies your devices with Bluetooth wireless technology.

Disabling Bluetooth

- 1 Select Settings > Bluetooth.
- 2 Select Bluetooth.

Traffic Settings

To open the traffic settings page, from the main menu, select **Settings > Traffic**.

Traffic: Enables traffic.

- Current Provider: Sets the traffic provider to use for traffic data. Auto selects the best available traffic data automatically.
- Subscriptions: Lists current traffic subscriptions.
- **Optimize Route**: Selects whether to use optimized alternate routes automatically or upon request (page 8).
- **Traffic Alerts**: Selects the traffic delay severity for which the device displays a traffic alert.
- trafficTrends: Enables the trafficTrends feature (page 9).

Units and Time Settings

To open the Units and Time settings page, from the main menu, select **Settings > Units & Time**.

Current Time: Sets the device time.

- **Time Format**: Allows you to select a 12-hour, 24-hour, or UTC display time.
- Units: Sets the unit of measure used for distances.

Position Format: Sets the coordinate format and datum used for geographical coordinates.

Language and Keyboard Settings

To open the Language and Keyboard settings, from the main menu, select **Settings** > **Language & Keyboard**.

Voice Language: Sets the language for voice prompts.

Text Language: Sets all on-screen text to the selected language.

NOTE: Changing the text language does not change the language of user-entered data or map data, such as street names.

Keyboard Language: Sets the language for your keyboard.

Device and Privacy Settings

To open the Device settings page, from the main menu, select **Settings > Device**.

About: Displays the software version number, the unit ID number, and information on several other software features.

EULAs: Displays the end-user license agreements that apply to your choice.

NOTE: You need this information when you update the system software or purchase additional map data.

- **Travel History**: Allows the device to record information for the myTrends, Where I've Been, and Trip Log features.
- Clear Travel History: Clears your travel history for the myTrends, Where I've Been, and Trip Log features.

Proximity Alerts Settings

Select Settings > Proximity Alerts.

- Audio: Sets the style of alert that plays when you approach proximity points.
- Alerts: Sets the type of proximity points for which alerts are played.

Restoring Settings

You can restore a category of settings or all settings to the factory default values.

- 1 Select Settings.
- 2 If necessary, select a settings category.
- 3 Select => Restore.

Appendix

Power Cables

Your device can be powered various ways.

- Vehicle power cable
- USB cable
- AC adapter (optional accessory)

Charging the Device

You can charge the battery in the device using any of these methods.

- · Connect the device to the vehicle power cable.
- Connect the device to a computer using the included USB cable.
- Connect the device to an optional power adapter accessory, such as a wall power adapter.

Changing the Fuse in the Vehicle Power Cable

NOTICE

When replacing the fuse, do not lose any of the small pieces and make sure they are put back in the proper position. The vehicle power cable does not work unless it is assembled correctly.

If your device does not charge in your vehicle, you may need to replace the fuse located at the tip of the vehicle adapter.

1 Unscrew the end piece 1.



TIP: You may need to use a coin to remove the end piece.

- 2 Remove the end piece, the silver tip 2, and the fuse 3.
- 3 Install a 2 A fast-blow fuse.
- 4 Place the silver tip in the end piece.
- 5 Screw the end piece back into the vehicle power cable ④.

Device Care

NOTICE

Avoid dropping your device.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touchscreen, or damage may result.

Cleaning the Outer Casing

NOTICE

Avoid chemical cleaners and solvents that can damage plastic components.

1 Clean the outer casing of the device (not the touchscreen) using a cloth dampened with a mild detergent solution.

2 Wipe the device dry.

Cleaning the Touchscreen

- 1 Use a soft, clean, lint-free cloth.
- 2 If necessary, lightly dampen the cloth with water.
- **3** If using a dampened cloth, turn off the device and disconnect the device from power.
- 4 Gently wipe the screen with the cloth.

Avoiding Theft

- Remove the device and mount from sight when not in use.
- Remove the residue left on the windshield by the suction cup.
- Do not keep your unit in the glove compartment.
- Register your device at http://my.garmin.com.

Mounting on Your Dashboard

NOTICE

The permanent mounting adhesive is extremely difficult to remove after it is installed.

Use the mounting disk to mount your device to the dashboard and comply with certain state regulations. See www.garmin.com for more information.

- 1 Clean and dry the dashboard where you are placing the disk.
- 2 Remove the backing from the adhesive on the bottom of the disk.
- 3 Place the disk on the dashboard.
- 4 Remove the clear plastic cover from the top of the disk.
- 5 Place the suction cup mount on top of the disk.
- 6 Flip the lever down (toward the disk).

Removing the Device, Mount, and Suction Cup

Removing the Device from the Mount

- 1 Press the release button on the bottom of the device.
- **2** Tilt the device forward.

Removing the Mount from the Suction Cup

- 1 Turn the device mount to the right or left.
- **2** Apply pressure until the socket on the mount releases the ball on the suction cup.

Removing the Suction Cup from the Windshield

- 1 Flip the lever on the suction cup toward you.
- **2** Pull the tab on the suction cup toward you.

Purchasing Additional Maps

- 1 Go to your device product page at (www.garmin.com).
- 2 Click the Maps tab.
- 3 Follow the on-screen instructions.

Purchasing Accessories

Go to http://buy.garmin.com.

Troubleshooting

The suction cup will not stay on my windshield

- 1 Clean the suction cup and windshield with rubbing alcohol.
- 2 Dry with a clean, dry cloth.

3 Mount the suction cup (page 1).

My device is not acquiring satellite signals

- Verify the GPS simulator is turned off (page 14).
- Take your device out of parking garages and away from tall buildings and trees.
- Remain stationary for several minutes.

The device does not charge in my vehicle

- Check the fuse in the vehicle power cable (page 15).
- Verify the vehicle is turned on and is supplying power to the power outlet.
- Verify the interior temperature of the vehicle is between 32° and 113°F (between 0° and 45°C).
- Verify that the fuse is not broken in the vehicle power outlet.

My battery does not stay charged for very long

- Decrease the screen brightness (page 14).
- Shorten the display timeout (page 14).
- Decrease the volume (page 2).
- Disable Bluetooth wireless technology (page 14).
- Put the device in sleep mode when not in use (page 1).
- Keep your device away from extreme temperatures.
- Do not leave your device in direct sunlight.

The battery gauge does not seem accurate

- 1 Allow the device to fully discharge.
- 2 Fully charge the device without interrupting the charge cycle.

My device does not appear as a removable drive on my computer

On most Windows computers, the device connects using Media Transfer Protocol (MTP). In MTP mode, the device appears as a portable device and not as a removable drive. MTP mode is supported by Windows 7, Windows Vista[®], and Windows XP Service Pack 3 with Windows Media Player 10.

My device does not appear as a portable device on my computer

On Mac computers and some Windows computers, the device connects using USB mass storage mode. In USB mass storage mode, the device appears as a removable drive or volume, and not as a portable device. Windows versions prior to Windows XP Service Pack 3 use USB mass storage mode.

My device does not appear as either a portable device or a removable drive or volume on my computer

- 1 Disconnect the USB cable from your computer.
- 2 Turn off the device.
- **3** Plug the USB cable into a USB port on your computer and into your device.

TIP: Your device should be connected directly to a USB port on your computer and not to a USB hub.

The device automatically turns on and goes into MTP mode or USB mass storage mode. A picture of the device connected to a computer appears on the device screen.

My phone will not connect to the device

Select Settings > Bluetooth.
 The Bluetooth field must be set to Enabled.

- Enable Bluetooth wireless technology on your phone and bring your phone within 33 feet (10 m) of the device.
- Go to www.garmin.com/bluetooth for more help.

Index

Symbols

```
2-D map view 7
3-D map view 7
```

accessories 15 active lane guidance 6 adding stops 5 addresses, finding 3 alerts audio 14 proximity points 14 safety cameras 14 answering calls 10 audio, proximity points 14 automatic volume 2 enabling 2 avoidances area 7 customizing 7 deleting 7 disabling 7 road 7 road features 7

R

backup camera 2 battery charging 1, 2, 15, 16 maximizing 16 problems 16 Bluetooth technology 10, 16 disabling 14 enabling 10 Bluetoothtechnology, settings 14 brightness 2

С

cables, power 15 calibrating fuel economy 12 calls 10 answering 10 call waiting 10 contacts 10 dialing 10 disabling 11 history 10 home 11 placing 10 cameras backup 2 safety 8 changing search area 3 charging the device 1, 2, 15, 16 cleaning the device 15 cleaning the touchscreen 15 computer, connecting 13, 16 coordinates 4 current location 7 custom POIs 5 customizing, avoidances 7 customizing the device 13

D

dashboard mount 15 deleting paired headset 10 trips 13 destinations. See locations detours 6 device care 15 dialing 10 directions 6 disconnecting phone 10 display settings 14 driving directions 6

Е

ecoChallenge 12 ecoChallenge score 12 resetting 12 ecoRoute 12 calibrating fuel economy 12 ecoChallenge score 12 HD accessory 11 mileage report 12 mileage reports 12 vehicle profile 11 ecoRoute HD, accessory 11 EULAs 14 extras custom points of interest 5 safety cameras 8

F

files supported types 13 transferring 13 finding locations. 3 See also locations addresses 3 browsing the map 3 categories 3 cities 4 coordinates 4 intersections 4 using the map 3 finding services 3 up ahead 6 fuel, prices 12 fuel economy. 12 See also ecoRoute fuel price, changing 12 fuse, changing 15

G

Garmin Express 1 registering the device 1 updating software 1 Garmin Live Services 11 subscribing to 11 aeocachina 4 going home 4 GPS 1, 2

н

hands-free phone calls 10 help. 11 See also product support home calling 11 editing location 4 going 4 phone number 10 setting locations 4

L

ID number 14 intersections, finding 4

junction view 6

Κ

keyboard 2 language 14 layout 14

language keyboard 14

L

voice 14 latitude and longitude 4 lifetime maps 1 locations 3, 13 calling 10 current 4, 7 recently found 4 saving 4 searching for 4 setting home 4

simulated 4

Μ

map, data field 7 map layers, customizing 7 map perspective 7 map tools 7 map view 2-D 7 3-D 7 maps 5, 6, 13 browsing 3 data field 6 detail level 13 layers 7 lifetime 1 nüMaps Guarantee 1 nüMaps Lifetime 1 purchasing 15 theme 13 updating 1 viewing routes 6 memory card 13 microSD card, installing 13 mileage reports 12 mount, removing 15 mounting the device automobile 1 dashboard 15 removing from mount 15 suction cup 1, 15 muting, audio 10 myGarmin, messages 12 myTrends, routes 7 Ν navigation 5 off-road 5 previewing routes 5 settings 14 next turn 6 nüMaps Guarantee 1 nüMaps Lifetime 1 0 off-road navigation 5 on-screen buttons 2 Ρ pairing 10 deleting paired headset 10 disconnecting 10 phone 10, 16 parking 4 last spot 11 phone disconnecting 10 pairing 10, 16 phone book 10 phone calls 10 answering 10 call waiting 10 dialing 10 muting 10 voice dial 10 POI. 5 See also point of interest (POI)

POI Loader 5

custom 5

extras 5

power cables 15

vehicle 1

power key 1

points of interest (POI)

POI Loader 5

product registration 1

product support 11

profiles, RV 2, 14

changing the fuse 15

proximity points alerts, settings 14

points of interest (POI Loader) 5

Q

Quick Search 3

R

recently found locations 4 registering the device 1 removing mount 15 renaming trips 13 reports, mileage 12 resetting device 1 trip data 7 restoring settings 15 road conditions, weather 12 routes calculating 5 myTrends 7 preferences 14 previewing 5 starting 5 stopping 6 suggested 7 viewing on the map 6 RV, profiles 1, 2, 14

s

safety cameras, database 8 satellite signals acquiring 1 viewing 2 saved locations 5, 13 categories 4 deleting 4 editing 4 saving, current location 4 screen, brightness 2 screenshots 14 search bar 3 settings 14 shortcuts adding 5 deleting 5 simulated locations 4 sleep mode 1 Smartphone Link 11 connecting 11 disabling calls 11 Garmin Live Services 11 software updating 1 version 14 speech recognition 9 stops, adding 5 subscriptions Garmin Live Services 11 nüMaps Lifetime 1 traffic 1 suction cup 15

Т

theft, avoiding 15 time settings 2, 14 traffic 8, 9, 14 activating a subscription 9 adding subscriptions 9 alternate route 8, 9 cameras 9 incidents 8 lifetime subscriptions 1 map 8 receiver 8 searching for delays 8 trafficTrends 9 traffic cameras 9 saving 9 viewing 9 trafficTrends 9 disabling 9 transportation modes 5 travel history 14

trip computer 6 resetting information 7 trip data, resetting 7 trip information 6 viewing 6 trip log, viewing 7 trip planner 12, 13 editing a trip 13 troubleshooting 15, 16 turn list 6

U

unit ID 14 up ahead customizing 6 finding services 6 up ahead services 6 USB, disconnecting 13

V

vehicle power cable 1 vehicle profile 1, 11 voice command 9, 10 activating 9 navigating with 9 tips for using 9 wakeup phrase 9 volume, adjusting 2

W

warning icons 6 warnings icons 6 weather 12 radar 12 road conditions 12 Where Am I? 4, 7

www.garmin.com/support



Garmin International, Inc. 1200 East 151st Street Olathe, Kansas 66062, USA

Garmin (Europe) Ltd. Liberty House, Hounsdown Business Park Southampton, Hampshire, SO40 9LR UK

Garmin Corporation No. 68, Zhangshu 2nd Road, Xizhi Dist. New Taipei City, 221, Taiwan (R.O.C.)



© 2013 Garmin Ltd. or its subsidiaries